


MOD-6003 QUEEN BED














Thank you for purchasing the **MODWAY BED!**

Before you start, here are some helpful advice:


1. We suggest you spend a short time reading through this leaflet and then follow the simple step instructions.
2. Owing to the size and weight of the bed, we recommend that it is assembled by two adults, on a carpeted or padded area, in the room that it is intended for. Approx assembly time: 30 minutes.
3. Please do not use any tools other than those provided or recommended in these instructions.
4. Please do not throw away any of the packaging or the instruction until you have checked all the components and hardware and the furniture is fully assembled. Please ensure that the packaging is disposed of in a safe environmentally friendly way.
5. Assemble all components loosely until advised to tighten. Depending on use, it may be necessary to tighten the components from time to time, so please save tools that have been provided.
6. Please keep all fitting out of reach of children.



Hardware:


1		JCBC BOLT M6 x 45	18 PCS
2		JCBB BOLT M8 x 50	16 PCS
3		SPRING WASHER M6	10 PCS
4		FLAT WASHER M6	8 PCS
5		SPRING WASHER M8	16 PCS
6		WOOD DOWEL M8 x 30mm	4 PCS
7		WOOD DOWEL M10 x 30mm	8 PCS
8		ALLEN KEY (BALL SHAPE) M4	1 PC
9		ALLEN KEY (BALL SHAPE) M5	1 PC
10		WOOD SCREW M4 x 38mm	9 PCS
11		FLAT WASHER M8	16 PCS

Component:



<table border="0"> <tr><td>A.</td><td>HEADBOARD</td><td>x 1</td></tr> <tr><td>B.</td><td>HEADBOARD WING (L&R)</td><td>x 2</td></tr> <tr><td>C.</td><td>HEADBOARD SUPPORT</td><td>x 1</td></tr> <tr><td>D.</td><td>FOOTBOARD</td><td>x 1</td></tr> <tr><td>E.</td><td>SIDE RAIL (L&R)</td><td>x 2</td></tr> <tr><td>F.</td><td>CENTER RAIL</td><td>x 1</td></tr> <tr><td>G.</td><td>CENTER SUPPORT LEG</td><td>x 3</td></tr> <tr><td>H.</td><td>LEG</td><td>x 4</td></tr> <tr><td>I.</td><td>BED SLAT</td><td>x 1</td></tr> <tr><td>J.</td><td>SIDE RAIL SUPPORT</td><td>x 2</td></tr> </table>	A.	HEADBOARD	x 1	B.	HEADBOARD WING (L&R)	x 2	C.	HEADBOARD SUPPORT	x 1	D.	FOOTBOARD	x 1	E.	SIDE RAIL (L&R)	x 2	F.	CENTER RAIL	x 1	G.	CENTER SUPPORT LEG	x 3	H.	LEG	x 4	I.	BED SLAT	x 1	J.	SIDE RAIL SUPPORT	x 2	
A.	HEADBOARD	x 1																													
B.	HEADBOARD WING (L&R)	x 2																													
C.	HEADBOARD SUPPORT	x 1																													
D.	FOOTBOARD	x 1																													
E.	SIDE RAIL (L&R)	x 2																													
F.	CENTER RAIL	x 1																													
G.	CENTER SUPPORT LEG	x 3																													
H.	LEG	x 4																													
I.	BED SLAT	x 1																													
J.	SIDE RAIL SUPPORT	x 2																													

STEP 1

1.1 Fasten center support leg (G) to center rail (F) attach by screwing the protruding nut into the corresponding holes.




1.2 Fit wood dowels (6) into HEADBOARD WING (L&R) (B).



TOOLS REQUIRED FOR ASSEMBLY



1.3 Fit wood dowels (7) into LEG (H).



TOOLS REQUIRED FOR ASSEMBLY




MOD-6003 QUEEN BED

STEP 2


2.1 Insert and secure the headboard wing (B) to the headboard (A) using hardware parts 4,3,1 and 8. Repeat the same for other side of headboard wing.

(Note : Don't screw tied).



1. JCBC BOLT M6 x 45 x 4pcs	3. SPRING WASHER M6 x 4pcs	4. FLAT WASHER M6 x 4pcs	8. ALLEN KEY (BALL SHAPE) M4 x 1pc

2.2 Insert and secure the leg (H) to the side rail (E) using hardware parts 2,5,11 and 9. Repeat the same for other side of leg.




2. JCBB BOLT M8 x 50 x 8pcs	5. SPRING WASHER M8 x 8pcs	11. FLAT WASHER M8 x 8pcs	9. ALLEN KEY (BALL SHAPE) M5 x 1pc





MOD-6003 QUEEN BED



STEP 3


3.1 Insert and secure the headboard support (C) and footboard (D) to the side rail (E) using hardware parts 2,5,11 and 9. Repeat the same for other side of side rail.



			
2. JCBB BOLT M8 x 50 x 8pcs	5. SPRING WASHER M8 x 8pcs	11. FLAT WASHER M8 x 8pcs	9. ALLEN KEY (BALL SHAPE) M5 x 1pc

STEP 4


4.1 Locate center rail (F) into the corresponding brackets inside of headboard support (C) and footboard (D).



STEP 5

5.1 Insert and secure the headboard (A) to the headboard support (C) using hardware parts 1,3,4 and 8. Repeat the same for other side of side rail.

(Note : Don't screw tied).




1. JCBC BOLT M6 x 45 x 4pcs	3. SPRING WASHER M6 x 4pcs	4. FLAT WASHER M6 x 4pcs	8. ALLEN KEY (BALL SHAPE) M4 x 1pc

STEP 6

6.1 Insert and secure the headboard wing (B) to the side rail (E) using hardware parts 1,3 and 8. Repeat the same for other side of side rail.


(Finish step 6, Please screw tied the step 2 bolt & step 5 bolt.)



1. JCBC BOLT M6 x 45 x 2pcs	3. SPRING WASHER M6 x 2pcs	8. ALLEN KEY (BALL SHAPE) M4 x 1pc

STEP 7

7.1 Insert and secure the side rail support (J) to the side rail (E) using hardware parts 1 and 8. Repeat the same for other side of side rail.





1. JCBC BOLT M6 x 45 x 8pcs	8. ALLEN KEY (BALL SHAPE) M4 x 1pc

MOD-6003 QUEEN BED




STEP 8

8.1 Assemble bed slat (I) into bed frame in between side rail (E) and center rail (F) screw it using hardware parts 10.



STEP 9

9.1 Carefully position the assembled bed to the desired location by four adults.



Assembly is complete. The bed is ready to use now!

NOTE: Hardware may loosen over time. Periodically check that all connections are tight.